

Wireless Token Dispenser

1. Download device firmware on your mobile/PC
2. Turn ON power to device using given power supply
3. Turn on WiFi on your mobile then **find out given device name on WiFi device list then** click it to connect, **password: 12345678.**
4. Open any web browser then enter <http://192.168.4.1/update> on address bar, click choose file to select downloaded firmware on step 1 then **click update firmware** then wait till update complete & device restart.

Technical support

WhatsApp: 9444896273

Email: sales@hextek.in