

# TOKEN CONTROL UNIT(KEYPAD) USER MANUAL



NO	Key name	Usage
1.	REPEAT	To recall previously called token
2.	RESET	To reset token control reset keypad
3.	LAST	To call previous/last token
4	NEXT/ENTER	To call next token(* this key has dual function)

**Note:** \* For direct token call, press your token number and then press NEXT/ENTER key

\* To call tokens sequentially, press NEXT/ENTER key alone.

**To reset token :** #000 then press enter/next key to reset token number to zero on token display.

**To select language:** #957 then press 0-Tamil , 2-Hindi 3-English then press next/enter key.

**To set device ID:** #759 then press 0 and 1 then press next/enter key, then 0 for standalone token system or 1 for computer based token system.